

AUTOLIFT SYSTEM

INSTALLATION MANUAL FOR
ADAPTERS **MERCEDES 316 since 2016**

Please subscribe to our Youtube channel TESA AUTOLIFT SYSTEM and see all tutorial videos.

Front left adapter Mercedes 316



Step 1: Insert the special plate in the hole present on the frame, put the adapter and push frontly.



Step 2: Then fix the adapter with the bolt M10 supplied.



**USE THE SAME PROCEDURE FOR THE FRONT
RIGHT ADAPTER**

Step 3: Fix the jack.



**JACKS WITH MOTOR TO THE OUTSIDE OF THE VEHICLE
AND ROTATION REAR**

Rear left adapter Mercedes 316

Step 1:



Put the adapter in the point illustrated, the rear support of the crossbow suspension

Step 2:



Insert the special plates and fix the adapter with the M8 bolts supplied



Step 3:



Fix the jack.

USE THE SAME PROCEDURE FOR THE REAR RIGHT ADAPTER

JACKS WITH MOTOR TO THE OUTSIDE OR INSIDE OF THE VEHICLE AND ROTATION REAR