



**RoadPro Ltd.**

3 Egerton Close, DAVENTRY, Northamptonshire, NN11 8PE, England

E-mail: [sales@roadpro.co.uk](mailto:sales@roadpro.co.uk)

Website [www.roadpro.co.uk](http://www.roadpro.co.uk)

## TESA AutoLift Installation

We do not install the AutoLift self-levelling system ourselves but work with reputable installers around the country. From north to south, these include:

- [Motorhome Services Scotland](#) – Perth, Scotland
- [Motorhome Centre](#) – Glasgow, Scotland
- [Camper Ni](#) – Hillsborough, N. Ireland
- [Jacques Towbars](#) - York
- [Rhino Installs](#) – Preston
- [Lincs Caravan & Motorhome Services](#) – Lincolnshire
- [Agri-Mech](#) – Matlock Derbyshire
- [Salop Towing](#) – Shrewsbury, Shropshire
- [S&G Leisure](#) - Buckinghamshire
- [Bristol Caravans](#) - Bristol
- [Motorhome Workshop](#) – Worthing, West Sussex
- [Marquis Motorhomes](#) – Poole, Dorset
- [Devon and Cornwall Motorhome and Caravan Service Repair Centre](#) – Plympton, Devon

Please contact one of these companies and they will be able to advise you.

The AutoLift system can be installed on most motorhomes as long as they conform to these basic requirements:

- **The vehicle has a GVW of no more than 5 tonnes.**
- **There is a minimum of 35cm clearance between the mounting points on the chassis and the ground. This is especially important for the front jacks on a Ducato. NOTE: Clearance will be affected when the vehicle is laden or if it has adjustable air suspension, so please take this into account.**
- **The vehicle's wheels are at least 16" in diameter. 15" may be OK but double-check that there is sufficient distance from the chassis to the ground for the front jacks to extend.**
- **Mounting brackets are supplied by TESA. You can see the available brackets on our website [here](#).**

The installation company will also require the following vehicle details:

- **Make of motorhome**
- **Base vehicle (Ducato, Mercedes Sprinter, Ford Transit, etc)**
- **Year of manufacture**
- **Chassis type (Ducato, Alko, Mercedes, Ford, etc)**
- **Tyres' radial number** (this is on the tyre wall usually three numbers / two numbers R?? ####/##R??)
- **Clearance: As explained above, there must be a minimum of 35cm clearance between the mounting points on the chassis and the ground. Clearance will be affected by tyre size, if the vehicle is laden or if it has adjustable air suspension, so please take these factors into account.**

Even motorhomes of the same model type can have variations on the underside. To make sure that the mounting brackets can be fitted, the installer may need to see the vehicle itself or photos of the vehicle's underside. See the examples on the following page.

[Click here to see the AutoLift system on our website](#) and, if you need any further assistance, please contact us via our website or email – [sales@roadpro.co.uk](mailto:sales@roadpro.co.uk).

Examples of photos needed to make sure the correct mounting adaptors are supplied.

